10-Key RF Remote Controller

Model No.: RM3

1 zone RGB or RGBW/10-key/Wireless remote 30m distance/CR2032 battery



C€ RoHS @MC LVD RED

Features

- Apply to RGB or RGBW LED controller.
- Each remote can match one or more receiver.
- CR2032 battery powered.
- Operate with LED indicator light.

Technical Parameters


Input and Output	
Output signal	RF(2.4GHz)
Working voltage	3VDC(CR2032)
Working current	<5mA
Standby current	< 2µA
Standby time	2 years
Remote distance	30m(Barrier-free space)

Environment	
Operation temperature	Ta: -30°C ~ +55°C
IP rating	IP20

Safety and EMC	
EMC standard (EMC)	EN301 489,EN 62479
Safety standard(LVD)	EN60950
Radio Equipment(RED)	EN300 328
Certification	CE,EMC,LVD,RED

Warranty		
Varranty	5 years	

Mechanical Structures and Installations



Note: Before the first use, please remove the protective film on the battery.

Match Remote Control (two match ways)

End user can choose the suitable match/delete ways. Two options are offered for selection:

Use the controller's Match key

Match:

Short press match key, immediately press on/off key on the remote. The LED indicator fast flash a few times means match is successful.

Delete:

Press and hold match key for 5s to delete all match, The LED indicator fast flash a few times means all matched remotes were deleted.

Use Power Restart

Match:

Switch off the power, then switch on power again, immediately short press on/off key 3 times on the remote. The light blinks 3 times means match is successful.

Delete:


Switch off the power, then switch on power again, immediately short press on/off key 5 times on the remote. The light blinks 5 times means all matched remotes were deleted.

Key function



On/Off: Turn on/off light.





- Mode+: Short press run the next dynamic mode, long press 2s run mode cycle.
- Mode -: Short press run the previous dynamic mode, long press 2s run the first mode.
- Bright/Speed+: For static RGB color, increase brightness,
 short press 10 levels, long press 1-ós for continuous 25ó levels adjustment.
 For dynamic mode, increase speed, short press 10 levels, long press get the fastest speed.
- Bright/Speed -: For static RGB color, deccrease brightness, short press 10 levels, long press 1-6s for continuous 256 levels adjustment. For dynamic mode, decrease speed, short press 10 levels, long press get the slowest speed.
- R/G/B: Short press get red green or blue color directly, long press 1-ós adjust R/G/B brightness continuouslyto achieve millions of colors.
- W+/-: For RGB light, short press turn on/off white (RGB mix), long press 1-ós adjust saturation continuously namely change current static RGB color to mixed white slowly.

 For RGBW light, short press turn on/off W channel, long press 1-ós adjust W brightness continuously

Safety information

- 1. Read all instructions carefully before you begin this installation.
- When installing battery, pay attention to the battery positive and negative polarity.
 A long time without the remote control, remove the battery.
 When remote distance becomes smaller and insensitive, replace the battery.
- 3. If no response from the receiver, please re-match the remote.
- 4. Gently handle remote, beware of falling.
- 5. For indoor and dry location use only.

User Manual Ver 1.0.2