

# U Series available in models...

KIWI

MODELK005UK007UK010UVa Rating500va750va1000vaAlso available in MultiWay (push button) configuration.

Black Conversion Kits available model KBC.

### electronics

### Installation

### Step 1 - adaptors

#### PDL:

- 600series fit the adaptor into the flush plate. Then fit the KIWI to the adaptor with locknut.
- Iconic fit the adaptor to the KIWI with locknut. Then fit the unit into the flush plate.
- For 600 and Iconic fit the locknut cover "stop" side up.
- Iconic only fit the shaft extension to the shaft.

#### HPM and Clipsal:

- Fit the adaptor to the KIWI with locknut.
- Fit the locknut cover, "stop" side up.
- Click the unit into the flush plate.

### Step 2 - plate

- Fit the face plate cover (if required).
- Slide the knob onto the shaft.

### Step 3 - electrical

- Connection is by way of the two red wires.
- Connect one to live and the other to load.
- Turn on at the isolator.

#### CHECK the current does NOT exceed the PEAK.

The KIWI will Soft Start to where the rotary knob has been set. The knob has a turning angle of 270 degrees and retains memory of where it was last set.

# **Extra Settings**



Minimum:Turn the minimum trimmer clockwise to raise the minimum light level the knob can be turned down to. The minimum level cannot be adjusted above the maximum. Turn up until lights are stable and operate as desired.

Maximum: Turn the maximum trimmer anti-clockwise to lower the maximum light level the knob can be turned to.

### Mode Switch Setting (BOTH TE and LE)

To change from Trailing Edge (TE) to Leading Edge (LE), rotate mode changing switch Anti Clockwise until it meets the stopper for LE and Clockwise for TE.

Note: the default settings are illustrated above.

# Wiring Diagram



Connect multiple loads in parrallel.

#### Warnings

· ALWAYS ensure there is adequate ventilation (ie. air movement across the heatsink).

· Output from this unit will decease if the thermal protection level is exceeded. In this event, increase ventilation.

• This unit is fitted with a thermal fuse. Exceeding a

continuous current of 16amps or failing to supply adequate ventilation it will permantly open circuit.

Do not exceed the specified Volt Amp (va) Rating.

• The KIWI UNIVERSAL Dimmer has been designed to be connected in series with the load. Do not connect between phase and neutral.

## Manufactured in NZ by: KIWI Electronic Design Ltd Freephone: 0800 820 821 Email: contact@kiwielectronics.co.nz Web: www.kiwielectronics.co.nz

Thermal Fuse Thermal Protection Knob Rotation

> EMC/RFI approval AS/NZS 4051 •

**Product Specifications** 

250volt

K005U - 4A

K007U - 6A

K010U - 8A

Inductive (LE)

Capacitive (TE)

Trailing Edge or Leading Edge (Selectable)

3 x K005U

2 x K007U

1 x K010U

16amp/110°C max

Activated above 70°C  $270^\circ$  with memory

(Ensure mounting method promotes air flow.)

25°C

50hz

0% to 99% of input

Input voltage

Frequency

Load rating

Switching type

Ambient temp

Max per flush box

Peak current

Output voltage

Designed to AS3100 Note: Specifications may change without notice.

# **Dimensions**



Note: Dimensions in milimetres (mm).

## **Parts Assembly**



### Mounting



Recommended mountings for multipule units.